

SLITTER AIR II

A

Applicable to Model I, Model II, and Model III slitter/scorers employing Razorset blades with 6 inch spacing between heads. (Wider spacing bumper available.)

D

The upgrade includes a new anvil roll stand, which allows for re-positioning of rollers downstream as the blade diameter decreases. Available as stand only (using existing roller) or as complete unit (roller and stand)

B

- Increases blade life
- Unbolt anvil from linear bearing and install adjustable anvil
- Install roller assembly
- Verify head bumper for correct spacing
- Align anvil with tooling

